Maintenance Schedule for Normal Conditions

Service at the indicated distance or time-whichever comes first	miles x 1000	10	20	30	40	50	60	70	80	90	100	110	120
	km x 1000	16	32	48	64	80	96	112	128	144	160	176	192
Check engine oil and coolant		Check oil and coolant at each fuel stop											
Replace engine oil		■	■	■	■	■	■	■	■	■	■	■	■
Rotate tires (Check tire inflation & condition at least once per month)		■	■	■	■	■	■	■	■	■	■	■	■
Replace engine oil filter		■	■	■	■	■	■	■	■	■	■	■	■
Inspect front and rear brakes			■		■		■		■		■		■
Check parking brake adjustment			■		■		■		■		■		■
Visually inspect the following items			■		■		■		■		■		■
Tie rod ends			■		■		■		■		■		■
Suspension components			■		■		■		■		■		■
Driveshaft boots			■		■		■		■		■		■
Brake hoses and lines (including ABS)			■		■		■		■		■		■
All fluid levels & condition of fluids			■		■		■		■		■		■
*Exhaust system			■		■		■		■		■		■
*Fuel lines & connections			■		■		■		■		■		■
Inspect and adjust drive belt				■			■			■			■
Replace dust and pollen filter				■			■			■			■
Replace transmission fluid	MT												■
	AT												■
Inspect idle speed		Every 110,000 miles (176,000 km) or 7 years											
Replace rear differential fluid (4WD)										■			
Service the following items at recommended intervals.													
Replace air cleaner element		Every 30,000 miles (48,000 km)											
Replace spark plugs		Every 110,000 miles (176,000 km)											
Inspect valve clearance		Inspect every 110,000 miles (176,000 km), otherwise adjust only if noisy											
Replace engine coolant		At 120,000 miles (192,000 km) or 10 years, then every 60k miles (96,000 km) or 5 years											
Replace brake fluid		Every 3 years (independent of mileage)											
*: Replace at 120,000 miles or 6 years, then every 90k miles or 5 years		$52.94	$52.94	$171.77	$52.94	$52.94	$171.77	$52.94	$52.94	$231.76	$52.94	$204.02	$321.75
#: See information on maintenance & emissions warranty													

Brake Fluid Flush: 124.95+tax