Maintenance Schedule for Normal Conditions

Service at the indicated distance or time-whichever comes first		miles x 1000	7.5	15	30	45	60	75	90	105	120			
		km x 1000	16	32	48	64	80	96	112	128	144			
Check engine oil and coolant			Check oil and coolant at each fuel stop											
Replace engine oil			Every 7,500 miles (12,000 km) or 12 months											
Rotate tires (Check tire inflation & condition at least once per month)			■	■	■	■	■	■	■	■	■			
Replace engine oil filter			■	■	■	■	■	■	■	■	■			
Inspect front and rear brakes			■	■	■	■	■	■	■	■	■			
Check parking brake adjustment			■	■	■	■	■	■	■	■	■			
Visually inspect the following items					■	■	■	■	■	■	■			
	Tie rod ends				■	■	■	■	■	■	■			
	Suspension components				■	■	■	■	■	■	■			
	Driveshaft boots				■	■	■	■	■	■	■			
	Brake hoses and lines (including ABS)				■	■	■	■	■	■	■			
	All fluid levels & condition of fluids				■	■	■	■	■	■	■			
	*Exhaust system				■	■	■	■	■	■	■			
	*Fuel lines & connections				■	■	■	■	■	■	■			
Inspect and adjust drive belt					■		■		■		■			
Replace transmission fluid	MT								■					
	AT								■					
Inspect idle speed										■				
Replace rear differential fluid (4WD)			Vehicle is not equipped with a rear differential											
Service the following items at recommended intervals.														
Replace air cleaner element			Every 30,000 miles (48,000 km)											
Replace timing belt, water pump, drive belts and engine coolant										■				
Replace spark plugs			Every 30,000 miles (48,000 km)											
Inspect valve clearance			At 30,000 miles (48,000) only											
Replace engine coolant			Replace at 45,000/75,000/105,000 miles											
Replace brake fluid			Every 3 years (independent of mileage)											
*: Replace at 120,000 miles or 6 years, then every 90k miles or 5 years			$52.94	$52.94	$425.83	$248.88	$171.77	$122.93	$435.83	$672.92	$230.89			
#: See information on maintenance & emissions warranty														

Brake Fluid Flush: 124.95+tax