Maintenance Schedule for Normal Conditions

| Service at the indicated distance or time-whichever comes first | | miles x 1000 | 7.5 | 15 | 30 | 45 | 60 | 75 | 90 | 105 | 120 | | | |
|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|
| | | km x 1000 | 16 | 24 | 48 | 72 | 96 | 120 | 144 | 168 | 192 | | | |
| Check engine oil and coolant | | | Check oil and coolant at each fuel stop | | | | | | | | | | | |
| Replace engine oil | | | ■ | ■ | ■ | ■ | ■ | ■ | ■ | ■ | ■ | | | |
| Rotate tires (Check tire inflation & condition at least once per month) | | | Rotate tires every 7,500 (12,000 km) | | | | | | | | | | | |
| Replace engine oil filter | | | ■ | ■ | ■ | ■ | ■ | ■ | ■ | ■ | ■ | | | |
| Inspect front and rear brakes | | | ■ | ■ | ■ | ■ | ■ | ■ | ■ | ■ | ■ | | | |
| Check parking brake adjustment | | | ■ | ■ | ■ | ■ | ■ | ■ | ■ | ■ | ■ | | | |
| Visually inspect the following items | | | ■ | ■ | ■ | ■ | ■ | ■ | ■ | ■ | ■ | | | |
| | Tie rod ends | | ■ | ■ | ■ | ■ | ■ | ■ | ■ | ■ | ■ | | | |
| | Suspension components | | ■ | ■ | ■ | ■ | ■ | ■ | ■ | ■ | ■ | | | |
| | Driveshaft boots | | ■ | ■ | ■ | ■ | ■ | ■ | ■ | ■ | ■ | | | |
| | Brake hoses and lines (including ABS) | | ■ | ■ | ■ | ■ | ■ | ■ | ■ | ■ | ■ | | | |
| | All fluid levels & condition of fluids | | ■ | ■ | ■ | ■ | ■ | ■ | ■ | ■ | ■ | | | |
| | *Exhaust system | | ■ | ■ | ■ | ■ | ■ | ■ | ■ | ■ | ■ | | | |
| | *Fuel lines & connections | | ■ | ■ | ■ | ■ | ■ | ■ | ■ | ■ | ■ | | | |
| Inspect and adjust drive belt | | | | | ■ | | ■ | | ■ | | ■ | | | |
| Replace transmission fluid | MT | | | | | | | | ■ | | | | | |
| | AT | | | | | | | | ■ | | | | | |
| Inspect idle speed | | | | | | | | | | ■ | | | | |
| Replace rear differential fluid (4WD) | | | Vehicle is not equipped with rear differential | | | | | | | | | | | |
| ***Service the following items at recommended intervals.*** | | | | | | | | | | | | | | |
| Replace air cleaner element | | | Every 30,000 miles (48,000 km) | | | | | | | | | | | |
| Replace spark plugs | | | Every 105,000 miles | | | | | | | | | | | |
| Inspect valve clearance | | | Inspect every 30,000 miles | | | | | | | | | | | |
| Replace engine coolant | | | Replace 45,000/75,000/105,000 miles | | | | | | | | | | | |
| Replace brake fluid | | | Replace 45,000/75,000/105,000 miles | | | | | | | | | | | |
| *: Replace at 120,000 miles or 6 years, then every 90k miles or 5 years | | | $52.94 | $52.94 | $92.89 | $247.88 | $92.89 | $122.93 | $337.78 | $809.32 | $92.89 | | | |
| #: See information on maintenance & emissions warranty | | | | | | | | | | | | | | |

Brake Fluid Flush: 124.95+tax