Maintenance Schedule for Normal Conditions

Service at the indicated distance or time-whichever comes first	miles x 1000	7.5	15	30	45	75	90	105					
	km x 1000	12	24	48	72	120	144	168					
Check engine oil and coolant		Check oil and coolant at each fuel stop											
Replace engine oil		■	■	■	■	■	■	■					
Rotate tires (Check tire inflation & condition at least once per month)		■	■	■	■	■	■	■					
Replace engine oil filter		■	■	■	■	■	■	■					
Inspect front and rear brakes			■	■	■	■	■	■					
Check parking brake adjustment			■	■	■	■	■	■					
Visually inspect the following items				■	■	■	■	■					
Tie rod ends				■	■	■	■	■					
Suspension components				■	■	■	■	■					
Driveshaft boots				■	■	■	■	■					
Brake hoses and lines (including ABS)				■	■	■	■	■					
All fluid levels & condition of fluids				■	■	■	■	■					
*Exhaust system				■	■	■	■	■					
*Fuel lines & connections				■	■	■	■	■					
Inspect and adjust drive belt							■	■					
Replace dust and pollen filter				■			■	■					
Replace transmission fluid	MT						■						
	AT						■						
Inspect idle speed													
Replace rear differential fluid (4WD)		Vehicle not equipped with rear differential											
Service the following items at recommended intervals.													
Replace air cleaner element		Every 30,000 miles (48,000 km)											
Replace timing belt, water pump, drive belts and engine coolant								■					
Replace spark plugs		Every 105,000 miles (168,000 km)											
Inspect valve clearance		Inspect every 110,000 miles (176,000 km), otherwise adjust only if noisy											
Replace engine coolant		Replace 45,000/75,000 miles or 3 years											
Replace brake fluid		Every 3 years (independent of mileage)											
*: Replace at 120,000 miles or 6 years, then every 90k miles or 5 years		$52.94	$52.94	$171.77	$247.88	$122.93	$436.69	$735.92					
#: See information on maintenance & emissions warranty													

Brake Fluid Flush: 124.95+tax